

845 SPRAYER

USER MANUAL

98-05349 R0



TeeJet®
TECHNOLOGIES

A Subsidiary of  **Spraying Systems Co.®**

Copyrights

© 2021 TeeJet Technologies. All rights reserved. No part of this document or the computer programmes described in it may be reproduced, copied, photocopied, translated, or reduced in any form or by any means, electronic or machine readable, recording or otherwise, without prior written consent from TeeJet Technologies.

Trademarks

Unless otherwise noted, all other brand or product names are trademarks or registered trademarks of their respective companies or organisations.

Limitation of Liability

TEEJET TECHNOLOGIES PROVIDES THIS MATERIAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED. NO COPYRIGHT LIABILITY OR PATENT IS ASSUMED. IN NO EVENT SHALL TEEJET TECHNOLOGIES BE LIABLE FOR ANY LOSS OF BUSINESS, LOSS OF PROFIT, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS, OR FOR INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY KIND, EVEN IF TEEJET TECHNOLOGIES HAS BEEN ADVISED OF SUCH DAMAGES ARISING FROM TEEJET TECHNOLOGIES SOFTWARE.

Table of contents

IMPORTANT SAFETY INFORMATION

VI

GENERAL WARNINGS AND PRECAUTIONS

VI

CHAPTER 1 – INTRODUCTION

1

POWER

1

Power on the Console	1
Power Off the Console	1
Automatic Shutdown	1

PROGRAM MENU GUIDELINES

2

Enter the Setup Modes	2
Advance to the Next Option.....	2
Edit a Setup Option.....	2
Exit the System Setup Mode.....	2

CHAPTER 2 – INSTALLATION

3

MOUNTING THE TEEJET 845 CONSOLE

3

Console Step 1 - Location	3
Console Step 2 - Mounting	3
Console Step 3 - Power Connection	3
Console Step 4 - Connecting Component Cables	4

CONNECTING THE TEEJET 845 CONSOLE

5

Connect Step 1 - Wiring Layout.....	5
Connect Step 2 - Making The Connection.....	6

CHAPTER 3 – SYSTEM SETUP MODE

8

SYSTEM SETUP OVERVIEW

8

PROGRAM MENU GUIDELINES

8

Enter the System Setup Mode	8
Advance to the Next Option.....	8
Edit a Setup Option.....	8
Exit the System Setup Mode.....	8
Save All Setting Values.....	9
Restore All Setting Values	9

INTRODUCTION

INSTALLATION

SYSTEM SETUP

APPLICATION SETUP

OPERATION

APPENDIX

845 Sprayer Control System®

INTRODUCTION

INSTALLATION

SYSTEM SETUP

APPLICATION SETUP

OPERATION

APPENDIX

SYSTEM SETUP DETAILS

9

Units	9
Restore Defaults	9
Speed Sensor Calibration	9
Distance Counter	10
Pressure Sensor Installed	10
Zero Pressure Reference	10
Maximum Pressure Rating	11
Minimum Pressure	11
Flow Meter Installed	11
Flow Meter Calibration	11
Flow Sensor Minimum Flow Capacity	13
Regulation Mode	13
Tip/Nozzle Spacing	13
Number of Sections	14
Tips/Nozzles per Section	14
Density Factor	14
Regulation Valve Type	14
Regulation Speed Factor	15
Section Valve Type	15
Tank Size	15
Minimum Tank Level	16
Communication Mode	16
Use GNSS Speed	16
Use External Rate	17
Simulated Ground Speed	17
Low Speed	17
High Speed	17
Minimum Speed	17

OEM MENU

18

CHAPTER 4 – APPLICATION SETUP MODE

19

APPLICATION SETUP OVERVIEW

19

PROGRAM MENU GUIDELINES

19

Enter the Application Setup Mode	19
Advance to the Next Option	19
Edit a Setup Option	19
Exit the System Setup Mode	19
Activate Density Factor	19

APPLICATION SETUP DETAILS

20

Target Application Rate	20
Known Pressure Value	20
Known Speed Calculation	20
Programmable Tip/Nozzle Reference Flow	20
Predefined Tip/Nozzle Selection	21

CHAPTER 5 – OPERATING INSTRUCTIONS

22

WORK SCREEN 22

BEFORE YOU GET STARTED 23

Sprayer Check 23

THE SPRAYING OPERATION 24

BOOM SECTIONS & SWITCHES 24

OPERATION FEATURES 25

Tank Level 25

View Tank Level 25

Adjust Tank Level 25

Clear Counters 25

Simulated Speed 25

Activate the Simulated Speed 25

Deactivate Simulated Speed 26

Manual/Automatic Regulation Mode 26

Boost Function 26

Increase/Decrease Target Application Rate 26

Reset Target Application Rate 27

Regulation Indicator 27

Automatic Power Down 27

Smart Sensing 27

Audible Alarms 28

APPENDIX A – USER SETTING NOTES

30

CONFIGURATIONS 30

INTRODUCTION

INSTALLATION

SYSTEM SETUP

APPLICATION SETUP

OPERATION

APPENDIX

IMPORTANT SAFETY INFORMATION

All safety related and operating instructions should be read before the system is operated. Safe operation of machinery is the operators responsibility. Safety procedures must be posted close to the equipment and clearly visible to and legible by the operator. Safety procedures should meet all company and local regulations, as well as MSDS-requirements. For assistance, contact a local dealer.

Safety Alert Symbol Definitions:



DANGER! This symbol is reserved for the most extreme situations where serious personal injury or death is imminent.



WARNING! This symbol indicates a hazardous situation that could result in serious personal injury or death.



CAUTION! This symbol indicates a hazardous situation that could result in minor or moderate personal injury.



NOTE: This symbol addresses practices in which the operator should be aware.

GENERAL WARNINGS AND PRECAUTIONS



DANGER!

- Read and follow instructions. If instructions are unclear after reading the manual, please contact a local dealer.
- Keep children away from equipment.
- Do not operate machinery under the influence of alcohol or any illegal substance.
- Some systems include a fan heater. Never cover the heater otherwise there will be a serious danger of fire!



WARNING! ELECTRICAL / SHOCK HAZARDS

- Before working on any particular component, make sure that all power supplies have been switched off and cannot be accidentally switched on.
 - Disconnect power leads before using an arc welder on equipment or anything connected to the equipment.
 - Systems including frequency drives have a risk of electric shock due to residual voltage. It is not permissible to open the equipment neither to disconnect the system or any quick connection until 5 minutes after the power has been removed.
 - Only operate the system from the power source indicated in the manual. If you are not sure of the power source, consult qualified service personnel.
 - Do not use a high pressure cleaner to clean electrical components. This could damage electrical components and subject the operator to risk of electrical shock.
 - The electrical supply to the equipment must be properly routed and connected to the equipment. All connections must meet the specified requirements.
-



WARNING! PRESSURIZED HYDRAULIC SYSTEMS

- Always wear personal protective equipment (PPE) when performing work on hydraulic systems.
- Adhere to the machine manufacture's approved maintenance instructions when working on the hydraulic system.
- Always turn equipment off when working on the hydraulic system. Take appropriate precautions when opening systems that have been previously pressurized.
- Be aware that hydraulic oil may be extremely hot and under high pressure.



WARNING! CHEMICAL HANDLING

- Always wear PPE when handling any chemical substance.
- Always follow safety labels and instructions provided by the chemical manufacturer or supplier.
- The operator should have full information on the nature and the quantity of the material to be distributed.
- **ADHERE TO FEDERAL, STATE AND LOCAL REGULATIONS REGARDING THE HANDLING, USE OR DISPOSAL OF AGRICULTURAL CHEMICALS.**



WARNING! PRESSURIZED SPRAY SYSTEM

- It is important to recognise proper safety precautions when using a pressurized spray system. Fluids under pressure can penetrate skin and cause serious personal injury.
- The system pressure should never exceed the lowest rated component. Always know your system and all component capabilities, maximum pressures and flow rates.
- Filters can only be opened when the manual valves in front of and behind the filter are in closed position. If any appliance has to be taken out of the piping, manual valves in front of and behind this appliance have to be in closed position. If they are reinstalled, make sure that this happens correctly, that this apparatus is well aligned, and that all connections are tight.
- The plumbing supply to the equipment should meet all company and local regulations and must be properly routed and connected to the equipment. All connections must meet the specified requirements.
- It is advised to drain and purge the liquid train when the equipment shall not be used for a longer period of time.



WARNING! AUTO STEERING SAFETY

- To prevent serious personal injury or death from being run over by the vehicle or automated motion of the steering system, never leave the vehicles operator seat with the system engaged.
- To prevent serious personal injury or death from being run over by the vehicle or automated motion of the steering system, verify the area around the vehicle is clear of people or obstacles before startup, calibration, tuning or engaging the system.
- Make sure equipment is tightly secured to the proper components.
- Never drive on public roads with system engaged.



CAUTION! EQUIPMENT SAFETY, MAINTENANCE, AND SERVICE

- The equipment should be operated only by properly trained, qualified personnel. They must have proven their skills in the operation of the equipment.
- Before using the equipment, the operator has to check if the equipment is in good condition and can be used safely. If not, the equipment cannot be used.
- All necessary PPE must be readily available to the operator at all times.
- Routinely check the system and components for wear and damage. Replace or repair when necessary.
- Only qualified authorised experts are allowed to repair or maintain the installation. The maintenance and operating instructions shall be rigidly observed and followed.
- A complete manual for the equipment must be available to the operator or maintenance technician at all times.



CAUTION! HARNESS CABLE AND HOSE SAFETY

- Routinely check all harness cables and hoses for damage or wear. Replace or repair when necessary.
- Do not route harness cables and hoses with sharp bends.
- Do not strap harness cables and hoses to lines with high vibration or spikes in pressure.
- Do not strap harness cables and hoses to lines transporting hot fluids.
- Protect harness cables and hoses from sharp objects, equipment debris, and material buildup.
- Allow sufficient length for harness cables and hoses to have free movement on sections that move during operation, and be sure that harness cables or hoses do not hang below the equipment.
- Allow sufficient clearance for harness cables and hoses from implement and machine operational zones.
- When cleaning equipment, protect harness cables from high pressure wash.



NOTE: TOUCH SCREEN CARE

- Keep sharp objects away from the touch screen device. Touching the screen with a sharp object could result in damage to the display.
- Do not use harsh chemicals to clean the console/display. The correct way to clean a console/display is to use a soft damp cloth or anti-static wipe, similar to cleaning a monitor on a computer.




NOTE: RECOMMENDED REPLACEMENT PARTS

- The system has been designed with components that work together to provide the best system performance. When the system requires replacement parts, only TeeJet recommended components should be used to maintain proper system operation and safety.

CHAPTER 1 – INTRODUCTION

Make sure that all hardware components are properly installed and tested. Before starting the programming process, confirm that the console and all sensors are working properly.

IMPORTANT! Before beginning, review the following Program Guidelines that control the programming process



POWER

Power on the Console

To power on the console:

1. Press and release the PROGRAM  button.




The console will initially display the software version at the top of the screen and the serial number of the console at the bottom of the screen.

After approximately 3 seconds, the console will enter the work screen.

NOTE: Keeping the PROGRAM  button pressed will keep the start screen visible until released.

Power Off the Console

To power off the console:

1. While pressing and holding the MINUS  button, press and release the PROGRAM  button.
2. Release the MINUS  button.

The console will save new information (area and volume counters) to memory before it powers down.

Pressing any key during the power off count down will cancel the shut off function.

Automatic Shutdown

With the Master Switch in the "OFF" position, the console will automatically shut down after 10 minutes of no inputs (or at the time specified in the Auto Power Down setting in the OEM Setup Mode).


845 Sprayer Control System

PROGRAM MENU GUIDELINES



Enter the Setup Modes

For either of the two setup modes, the Master boom switch must be off.


System Program Menu

Press and hold the PROGRAM  button until the Program System Menu screen appears (approximately 3 seconds). See Chapter 3 for additional details.


User Program Menu


Press and release the PROGRAM  button once so the User System Menu screen appears. Press and release the PROGRAM  button again within 3 seconds to enter the setting options. See Chapter 4 for additional details.



Advance to the Next Option



Press the PROGRAM  button to advance the system to the next Program step. After the final setup option is complete, the console will return to the initial setup option.



Edit a Setup Option

Press the PLUS  button to increase the value or go to the next option on the list.

Press the MINUS  button to decrease the value or go to the previous option on the list.

For some Program options, press and hold the PLUS  button or MINUS  button to quickly change the values.

Press and release the PLUS  button and MINUS  button simultaneously to reset the value to "0".

For some Program options, press and hold the PLUS  button and MINUS  button simultaneously to enter Automatic Calibration mode.

Exit the System Setup Mode

Press and hold the PROGRAM  button for 3 seconds.

The inputs are stored, and the console will exit the setup mode.

CHAPTER 2 – INSTALLATION

MOUNTING THE TEEJET 845 CONSOLE


Console Step 1 - Location

Determine the best location for the control console in the cab or operator's compartment. Allow sufficient clearance, approximately 4 through 5"/10 through 12 cm to accommodate for the cable that will be connected to the right side of the console.

Console Step 2 - Mounting

Mount the console to a firm support within the cab area, and secure using the slots provided on the top, back, or bottom of the Console. Although two simple brackets are supplied with the unit, some additional bracketing may be necessary. The slots in the 845 will accept 1/4" / 6 mm bolts.

Figure 2-1: Brackets Provide Angle Adjustment



Console Step 3 - Power Connection


Locate the power cable that has a black connector on one end and two battery terminal rings on the other. Extend the battery terminal ring end of this cable from the cab to the battery.

NOTE: Make sure there are a total of 12 Volts delivered to the controller by connecting to the (+) terminal on one battery and the (-) terminal on the other battery. Reliable operation of the 845 Sprayer Control depends on a clean power supply. Ensure this by connecting the power cables directly to the battery and not to another power source.

Connect the battery terminal rings to the battery posts, making sure that the positive (red) and negative (black) wires correspond with the polarity of the battery terminals.

NOTE: The power cable is designed to provide the simple addition of a remote Master Switch in a convenient location (i.e. on the throttle, gear shift, or floor switch). To install a remote boom switch, simply install a switch to the blue wire in the power cable. The switch should be rated to handle the total current used by all boom section valves combined. If installed, the remote master switch will operate in series with the boom switches on the console.

Connect the battery cable to the power cable lead that extends from the main cable.

Test the installation by pressing the PROGRAM  button once to turn the 845 console on. If the display shows information, you have wired the power correctly.




NOTE: The TeeJet 845 Sprayer Control has an Automatic Power Down feature. With the Master Switch in the "OFF" position, the 845 will automatically shut down after 10 minutes of no inputs or at the time specified in the Auto Power Down setting in the OEM Setup Mode. This prevents possible battery drainage. To turn the console "OFF" with the Master Switch located in the "OFF" position, press and hold the MINUS  button while pressing the PROGRAM  button once, and then releasing both buttons. The console will shut down providing no other buttons are pressed.

Figure 2-2: Power Connection



845 Sprayer Control System

INTRODUCTION

INSTALLATION

SYSTEM SETUP

APPLICATION SETUP

OPERATION

APPENDIX

Console Step 4 - Connecting Component Cables

Once the console is installed, connecting it to the other components of the 845 system can begin. The standard kit contains a main cable that attaches to the master valve (optional), boom control valves, the pressure regulating valve, flow meter, and/or pressure sensor, and a proximity speed sensor or radar speed sensor. Lay out each of the valve and sensor leads before installing the sprayer components to be sure the cables are long enough in length from the sensor connections to the 845 console connection. If installation requires longer cables, several extension cables are available. If an exit hole has to be cut in the cab, be sure the edges are deburred and protected to prevent damage to the cables.

Figure 2-3: Wiring Diagram





Figure 2-4: Wiring Layout



845 Sprayer Control System

INTRODUCTION

INSTALLATION

SYSTEM SETUP

APPLICATION SETUP

OPERATION

APPENDIX

Connect Step 2 - Making The Connection

Now, extend the cable leads to the Flow Meter or Pressure Sensor, and GNSS Speed Sensor to the furthest component. Select the appropriate lead and connect to this component. Run the cable to the other component, taking care to safely secure the cable along the route.

Refer to the wiring layout on page 5.

Repeat this procedure with the cable leads to the Pressure Regulating Valve and the Boom Control Valves.

Figure 2-5: Console Connector


Console Connector	Pin No.	Wire Color	Signal Name
	A	Blue	Boom Sensor 12v Out
	B	White	Boom 1
	C	Brown	Boom 2
	D	Green	Boom 3
	E	Yellow	Boom 4
	F	Gray	Boom 5
	R	White/Red	Flow Meter
	S	White	Pressure Sensor
	T	White/Green	Speed Sensor
	V	Brown	Sensor(+V) Out
	a	White	Regulation Valve (+)
	b	Brown	Regulation Valve (-)
	c	Blue	+12v Boom Master In
	d	Green	Ground
	e	Red	Console Power In

Figure 2-6: Power Connector


Power Connector	Pin No.	Wire Color	Signal Name
	1	Brown	+12 VDC 845
	2	Blue	+12 VDC Master Switch
	3	Yellow/Green	Ground

Figure 2-7: Speed Sensor Connector


Speed Sensor Connector	Pin No.	Wire Color	Signal Name
	A	Brown	Power Out
	B	White	Speed Signal
	C	Green	Ground

Figure 2-8: Pressure Sensor Connector


Pressure Sensor Connector	Pin No.	Wire Color	Signal Name
	A	White	Power Out
	B	Black	Pressure Signal
	C	N/C	

Figure 2-9: Flow Sensor Connector



Flow Sensor Connector	Pin No.	Wire Color	Signal Name
	A	Brown	Power Out
	B	White	Flow Signal
	C	Green	Sensor Ground

Figure 2-10: Regulator Connector

Regulator Connector	Pin No.	Wire Color	Signal Name
	1	White	Regulation Valve (+) To Include Flow in ByPass Mode — +12v
	2	Black	Regulation Valve (-) To Include Flow in ByPass Mode — Ground

CHAPTER 3 – SYSTEM SETUP MODE

The System Setup Mode contains the programming steps that customize the controller to the sprayer components. These include the calibration steps and parameters that seldom change once programmed.

SYSTEM SETUP OVERVIEW

The following options are available in System Setup Mode. After the final setup option is complete, the console will return to the initial setup option.

- ▶ Units
 - ▶ Restore Defaults
- ▶ Speed Sensor Calibration
- ▶ Distance Counter
- ▼ Pressure Sensor Installed
 - ▶ Pressure Sensor, Low Pressure Calibration
 - ▶ Pressure Sensor, Maximum Rating
- ▶ Minimum Pressure
- ▼ Flow Meter Installed*
 - ▶ Flow Meter Calibration
 - ▶ Flow Sensor Minimum Flow Capacity
- ▶ Regulation Mode*
- ▶ Tip/Nozzle Spacing*
- ▶ Number of Sections*
- ▶ Tips/Nozzles per Section*
- ▶ Density
- ▶ Regulation Valve Type
- ▶ Regulation Speed Factor
- ▶ Section Valve Type*
- ▶ Tank Size
- ▶ Minimum Tank Level
- ▼ Communication Mode
 - ▶ GNSS Speed
 - ▶ Variable Rate
- ▶ Simulated Ground Speed – Low Speed
- ▶ Simulated Ground Speed – High Speed
- ▶ Minimum Speed

*Not available if a lane spraying unit is selected.

PROGRAM MENU GUIDELINES

Enter the System Setup Mode

The Master Switch must be off.




Press and hold the PROGRAM  button until the Program System Menu screen appears (approximately 3 seconds).


Figure 3-1: System Program Menu






Advance to the Next Option



Press the PROGRAM  button to advance the system to the next Program step. After the final setup option is complete, the console will return to the initial setup option.



Edit a Setup Option

Press the PLUS  button to increase the value or go to the next option on the list.

Press the MINUS  button to decrease the value or go to the previous option on the list.

For some Program options, press and hold the PLUS  button or MINUS  button to quickly change the values.

Press and release the PLUS  button and MINUS  button simultaneously to reset the value to "0".



Press and hold the PLUS  button and MINUS  button simultaneously for 3 seconds to enter Automatic Calibration mode in some steps.

Exit the System Setup Mode


Press and hold the PROGRAM  button for 3 seconds.


The inputs are stored, and the console will exit the setup mode.

Save All Setting Values



At any time in Setup Mode, press PROGRAM  button and PLUS  button simultaneously for 3 seconds to enter the Save All Setting Values option.



IMPORTANT: This is a safety backup function. Values are always stored when leaving the menu.


Use the PLUS  button or MINUS  button to select YES or NO.

Press the PROGRAM  button to advance to the next menu option.

Restore All Setting Values

At any time in Setup Mode, press PROGRAM  button and MINUS  buttons simultaneously for 3 seconds to enter the Restore All Setting Values option.

Use the PLUS  button or MINUS  button to select YES or NO.

Press the PROGRAM  button to advance to the next menu option.

SYSTEM SETUP DETAILS

Units

1. Select the units for operation. Options include:

- ▶ SI – bar, liters per hectare, kilometers per hour
- ▶ US – pounds per square inch, gallons per acre, miles per hour
- ▶ Turf – pounds per square inch, gallons per 1,000 square feet, miles per hour
- ▶ NH3 – ammonia
- ▶ IMP (Imperial) – pounds per square inch, gallons per acre, miles per hour
- ▶ LM2 – bar, liters per 100 square meters, kilometers per hour
- ▶ GLM – psi, gallons per mile, miles per hour (Lane spraying)
- ▶ LKM – bar, liters per kilometer, kilometers per hour (Lane spraying)

Figure 3-2: Units





Figure 3-3: Reset Defaults



Restore Defaults

If the units of measurement are changed, default values for all settings must be restored.

1. Select from:

- ▶ Yes – units WILL be changed, and value WILL be reset.
- ▶ No – units will NOT be changed, and value will NOT be reset.

NOTE: This has no effect on settings in the OEM menu.

Speed Sensor Calibration

Set number of speed Pulses per 100 meters / 300 feet.





1. Press the AUTO/MAN  button to establish if a Wheel sensor or Radar sensor is being used.
2. If necessary, run the Automatic Calibration to determine the number of pulses.
3. Enter the number of pulses.

Figure 3-4: Speed Sensor Calibration



Automatic Calibration

It is best to perform the automatic speed calibration process at least twice and use the average of the speed calibration numbers. The automatic speed calibration process should take place with the sprayer tank 1/2 full.

1. Mark off a distance of exactly 300 feet / 100 meters.*
2. Press and hold the PLUS  and MINUS  buttons simultaneously for 3 seconds to enter automatic calibration mode.

845 Sprayer Control System

INTRODUCTION






INSTALLATION

SYSTEM SETUP

APPLICATION SETUP

OPERATION




APPENDIX


3. Start driving toward the start point of the 300 foot / 100 meter course.
4. As the starting point is crossed, press the PLUS  button once to begin the calibration process. The 845 will count the Pulses generated while the course is driven.
5. As the ending point is crossed, press the PLUS  button once. The number displayed on the screen is the speed calibration number.
6. To accept the value, press the PROGRAM  button. To edit the value, use the PLUS  button or MINUS  buttons.

The number of Pulses is automatically stored as the new calibration.

*To confirm Automatic Speed Calibration distance, first complete the calibration procedure. Advance to the Distance Counter step. Drive the vehicle across the same 300 foot / 100 meter course, turning the Master Switch "ON" at the starting point and "OFF" at the finish point. The distance measured should be 300 feet / 100 meters (+/- 6 feet/+/- 1.8 meters).

Figure 3-5: Speed Sensor Automatic Calibration

 	
Speedcal.	250
wheel	CAL
Use +/- keys to set speed pulses Hold + and - keys 3 secs to autocal.	
 P	

NOTE: When the Automatic Calibration Mode is activated, no other functions are possible until the console receives Pulses for calibration. To deactivate the Automatic Calibration Mode, press the PLUS  button until a number is displayed.

Distance Counter

The Distance Counter step is not a calibration step. It is a help function that can be used to measure a distance such as to confirm Automatic Speed Calibration. No value can be entered here. This feature measures distance in feet/meters.

When using this function all section switches must be set to off to avoid spraying.

1. Turn Master Switch on to start distance counter.
2. Drive the desired distance.
3. Turn Master Switch off to stop distance counter.





To clear an existing distance value, press and hold the PLUS  and MINUS  buttons simultaneously for 3 seconds.

Figure 3-6: Distance Counter



	
Distance	0
count	feet
Use Master ON to measure distance (Close sections to avoid spraying)	
 P	

Pressure Sensor Installed

Select if a pressure sensor is installed.

If a flow sensor is not installed, this step is automatically set to "Yes" and cannot be changed.

Figure 3-7: Pressure Sensor Installed

	
Press	Yes
sensor	
Use +/- keys to set pressure sensor available or not	
 P	



Zero Pressure Reference

This step is available if "Pressure Sensor Installed" is set to "Yes".

The Zero Pressure Reference is used to calibrate the zero pressure setting of the pressure sensor installed on the system. The pressure sensor used with the console is a current type sensor and uses a 4-20 mA reading. "4.0 mA" represents "zero" pressure.

1. If necessary, run the Automatic Calibration to determine the Zero Pressure Reference setting.
2. Enter the value for the Zero Pressure Reference setting.

Figure 3-8: Pressure Sensor, Zero Pressure

	
Press	4.0
ref.	mA
Use +/- keys to set zero pressure ref. Hold + and - keys 3 secs to autocal.	
 P	

Automatic Calibration

Make sure that the sprayer pump is turned off and that there is absolutely no pressure in the system (release pressure held by boom control valves and Tip/Nozzle body check valves).

In some cases, it may be best to remove the sensor from the plumbing system to complete the calibration.







1. Press and hold the PLUS  and MINUS  buttons simultaneously for 3 seconds to start auto calibration mode. The lower left portion of the display will count from 1 through 10 during the calibration. Once the display finishes counting, it should display a number close to 4.0 (+/- 0.2).
2. To accept the value, press the PROGRAM  button. To edit the value, use the PLUS  button or MINUS  buttons.

Figure 3-9: Zero Pressure Reference Automatic Calibration




Maximum Pressure Rating

This step is only available if "Pressure Sensor Installed" is set to "Yes".

The Maximum Pressure Rating is used to establish the maximum rating of the pressure Sensor in the system. This number can be found stamped on the pressure sensor itself.

NOTES: Do not change the value to "0" even if there is no pressure sensor installed. The Maximum Pressure cannot be set lower than the Minimum Pressure. The Minimum Pressure defaults to 10 psi / 0.6 bar, below this value regulation is stopped.


Figure 3-10: Maximum Pressure Rating



Minimum Pressure

Below the Minimum Pressure value, regulation is stopped, except when using lane spraying (GLM or LKM).

Figure 3-11: Minimum Pressure




Flow Meter Installed

Select if a flow meter is installed.

If a pressure sensor is not installed this step is automatically set to "Yes" and cannot be changed.

If lane spraying is selected under Units (GLM or LKM), this setting will always be set to "Yes" and cannot be changed.

Figure 3-12: Flow Meter Installed




Flow Meter Calibration

This step is only available if "Flow Meter Installed" is set to "Yes".


Flow Meter Calibration determines the flow meter Pulses based on a known volume of fluid.

1. If necessary, run the Automatic Calibration to determine the number of pulses.
NOTE: The automatic calibration procedure is recommended for maximum accuracy.
Or note the flow meter calibration number found on the factory calibrated tag.
2. Enter the number of pulses.

Pressing the AUTO/MAN  button will switch between normal value and decimal value (/10). Decimal values can be used with very low flow calibration values to improve regulation accuracy.

845 Sprayer Control System

Figure 3-13: Flow Meter Automatic Calibration



Automatic Calibration





A volume of at least 50 gallons / 200 liters should be sprayed during the calibration. The more volume used for calibration, the more accurate the flow meter will be.

1. Press and hold the PLUS and MINUS buttons simultaneously for 3 seconds to start automatic calibration mode. This will clear the existing value and initiate the calibration procedure.
2. Engage the sprayer pump.
3. Turn the boom sections on and begin spraying a predetermined volume of fluid (i.e., 100 gallons / 300 liters).

As the predetermined amount is sprayed, the console will count the pulses.
4. After the predetermined volume has been sprayed, turn the Master Switch off to stop counting pulses.
5. Press the PROGRAM button to advance to the next step.
6. Use the PLUS and MINUS buttons to enter the actual volume sprayed (gallons / liters).
7. Press the PROGRAM button to exit Automatic Calibration.
8. To accept the value, press the PROGRAM button.

To edit the value, use the PLUS or MINUS buttons.

Figure 3-14: Flow Meter Automatic Calibration




Flow Sensor Minimum Flow Capacity

This step is only available if “Flow Meter Installed” is set to “Yes” and the console is programmed for use with a pressure sensor.

Set the minimum flow capacity for the installed flow sensor. Below the minimum flow capacity, regulation will switch to pressure mode. When flow capacity once again reaches an acceptable level for the flow meter to regulate, the console automatically switches back to flow based regulation.

Figure 3-15: Flow Sensor Minimum Flow Capacity



Minimum flow capacity can be located in the flow meter manufacturer's literature.


Regulation Mode

This step is only available when both a Flow Meter and a Pressure Sensor are installed. This step is automatically set to “Flow” and cannot be changed if lane spraying is selected (GLM or LKM).

Selecting a regulation mode will determine which sensor is used as the primary mode for regulation.

1. Select from:
 - Flow – the flow meter will be used to control flow and the pressure transducer will be used only to display the actual pressure.
 - Pressure – the pressure sensor will be used to control the flow and display the actual pressure.

Figure 3-16: Regulation Mode




Tip/Nozzle Spacing

This setting is not available if lane spraying is selected (GLM or LKM).

Select the space between Tips/Nozzles. Spacing must match the physical spacing on the sprayer.

Figure 3-17: Tip/Nozzle Spacing



845 Sprayer Control System

INTRODUCTION

INSTALLATION

SYSTEM SETUP

APPLICATION SETUP

OPERATION

APPENDIX

Number of Sections

This setting is not available if lane spraying is selected (GLM or LKM).

Select the number of sections. The number of sections must match the physical number of sections on the sprayer.

Figure 3-18: Number of Sections

P_{RO}	
No. of	5
sections	
Use +/- keys to set no. of sections	

Tips/Nozzles per Section

This setting is not available if lane spraying is selected (GLM or LKM).

Set number of Tips/Nozzles for each section. Each section programmed in the Number of Sections setting will have a separate setting to set the number of Tips/Nozzles per section.

Figure 3-19: Tips/Nozzles per Section

P_{RO}	
Sect.	6
1	nozzles
Use +/- keys to set no. of nozzles for the selected boom section	

Density Factor

Density Factor establishes the weight per volume setting based on the type of fertilizer being used. The fertilizer's ability to flow is affected by a number of factors. These factors may vary with each batch and it may change due to weather (humidity, etc.). To accommodate for this, the console uses a density factor to compensate for the nature of the applied fertilizer.

Density factor is activated/deactivated in Application Setup Mode.

Figure 3-20: Density Factor

P_{RO}	
Density	1.00
Use +/- keys to set density	

Regulation Valve Type

The Regulation Valve Type instructs the console where the regulating valve is plumbed into the system. Once configured correctly, this value should not change unless the regulating valve is physically moved to a new point in the plumbing.

1. Select from:
 - ▶ Throttle – the pressure regulating is plumbed in a supply line to the booms. With the controller in Manual Mode, the pressure regulating valve should open when the PLUS button is pressed or close when the MINUS button is pressed.
 - ▶ Bypass – the pressure regulating valve is plumbed in a bypass line. With the controller in Manual Mode, the pressure regulating valve should close when the PLUS button is pressed or open when the MINUS button is pressed.
 - ▶ PWM – a pulse width modulator is being used

Figure 3-21: Regulation Valve Type

P_{RO}	
Reg.	BYPASS
valve	type
Use +/- keys to select type of regulation valve	

Regulation Speed Factor

Operating conditions may necessitate a higher or lower response speed for the regulating valve. Any combination of numbers between 0.0 and 9.9 can be selected.

The first digit sets the speed for the coarse adjustment in relation to a large percentage outside of the target application rate.

The second digit sets the speed for the fine tune adjustment in relation to a small percentage close to the target application rate.




If your system is plumbed in a bypass mode, the Regulation Speed Factor of 9.5 works very well in most applications.

If your system is plumbed in a throttling mode, start with a Regulation Speed Factor of 5.5 and adjust the number according to your application requirements. Low flow situations will require a slower response time.

NOTES: The Regulation Speed Factor can be adjusted to optimize system performance. If the valve searches for the programmed application rate by cycling the pressure up and down continuously, reduce the Fine Adjustment Factor until the searching is minimized or eliminated. A higher number will increase the valve response speed and increase the rate of adjustment.

Figure 3-22: Regulation Speed Factor




Section Valve Type

This setting is not available if lane spraying is selected (GLM or LKM).

The Section Valve Type distinguishes the type of On/Off boom control valves installed on the machine. There are 2 types of valves that can be used:

1. Select from:
 - ▶ 2-way – control valve is simply an On/Off valve. Flow is either directed to the boom section(s) or it is blocked.
 - ▶ 3-way – control valve is known as a Bypass valve. Flow continuously passes through this valve. When the valve is activated (on), flow is directed to the boom section(s). When the valve is not activated (off), flow is directed through a bypass port back to the supply tank.


Figure 3-23: Section Valve Type



Tank Size

Sets the maximum tank size.

Figure 3-24: Tank Size



845 Sprayer Control System

INTRODUCTION

INSTALLATION

SYSTEM SETUP

APPLICATION SETUP

OPERATION


APPENDIX

Minimum Tank Level

Sets the tank level at which an alarm will trigger.

Setting this value to 0 will disable the tank alarm.

Figure 3-25: Minimum Tank Level

P_{RO}	
Tank	25
minimum	gal
Use +/- keys to set minimum tank level (set to 0 to disable alarm)	
 P	


Communication Mode

The Communications step allows for the selection of the type of communications (if any) used.

Select from:

- ▶ None – no external communications
- ▶ GPS speed – global position satellite system capability
- ▶ MT-98 VR+speed – variable application rate communications
- ▶ TJ844 Var.Rate – variable application rate communications
- ▶ TEEJET NMEA log
- ▶ LOG special

Figure 3-26: Communications Mode

P_{RO}	
Comm.	None
mode	
Use +/- keys to select serial communication mode	
 P	

GPS Speed

The GNSS receiver must be sending the GPVTG string at 19200 Baud or MidTech98 messages at 9600 Baud with a sampling rate of 1 Hz. Additional strings may also be sent.

Connect the GNSS receiver to the console using a 45-20063 serial cable.

When the console starts receiving speed information from the GNSS receiver, it uses that information for determining vehicle speed. If the console loses communications for more than 5 seconds, it will revert to other sources of speed input. If communications are regained, the console will automatically switch back to GNSS Speed.

Variable Rate Communications

The communication device must be sending the MidTech98 messages (MT-98 VR+speed) or Rockwell Vision messages (TJ844 Var.Rate) at 9600 Baud which contain variable rate info (prescription data). Additional strings may also be sent.


Variable rate communications will be used as the target application rate. If the console loses communications for more than 10 seconds, it will continue using the last received target application rate. If communications are regained, the console will automatically switch back to variable rate application.

Use GNSS Speed

This setting is only available if communication mode is set to “GPS speed” or “MT-98 VR+speed”.

GNSS Speed allows the console to accept speed data from an external GNSS source. Select either “Yes” to use the external GNSS Speed input, or “No” to ignore external speed input.

Figure 3-27: Use GNSS Speed


P_{RO}	
Use GPS	Yes
speed	
Use +/- keys to select use of GPS speed or not	
 P	

Use External Rate

This setting is only available if communication mode is set to “MT-98 VR+speed” or “TJ844 Var.Rate”.

Variable Rate is used to indicate whether local control rates are to be used or ignored. When set to “No”, the console will ignore the rate coming from the variable rate device and use its own preset rate. When set to “Yes”, the console will use the rate determined by the variable rate device, usually as determined from a prescription map.

Figure 3-28: Use External Rate







Simulated Ground Speed

Simulated ground speed allows the verification of console functions and the sprayer without actually moving the sprayer.

The console has a low and high simulated ground speed that allows for switching between the two to simulate a speed change. This will ensure that the console is regulating properly during sprayer checkout.

To activate the simulated speed, while on the work screen without the machine in motion and the Master Switch in the “ON” position:


- ▶ While pressing and holding the PROGRAM  button, press and release the MINUS  button simultaneously for low simulated speed.
- ▶ While pressing and holding the PROGRAM  button, press and release the PLUS  button for high simulated speed.

NOTE: Once the sprayer begins moving and the console receives actual speed pulses, simulated ground speed is deactivated. If a Radar/GNSS Speed Sensor is being used, disconnect the Radar/GNSS from the main console. Due to the sensitivity of this speed sensor, any movement can disable simulated speed.

Low Speed

Set simulated low speed.


Figure 3-29: Simulated Ground Speed – Low Speed



High Speed

Set simulated high speed.

Figure 3-30: Simulated Ground Speed – High Speed



Minimum Speed


Set the minimum speed at which the console automatically shuts the boom sections off to eliminate an operator function when slowing to stop or turn around. There will be no spraying below this speed.

When the sprayer speed exceeds the established Auto Master Off Speed, the boom sections turn back on.

Set this value to “0” to disable.

This feature is disabled when operating in Manual Mode.

Figure 3-31: Minimum Speed



OEM MENU

The OEM menu is normally only used by the OEM manufacturer for setting up machine specific parameters. For assistance with an option in the OEM menu, contact customer service for assistance.

OEM options include:

- ▶ Minimum Regulating Valve Voltage
- ▶ Regulation Dead Band
- ▶ Regulation Time from Minimum to Maximum
- ▶ PWM Minimum
- ▶ PWM Maximum
- ▶ PWM Frequency
- ▶ Display Stabilization Percentage
- ▶ Master Relay Installed
- ▶ Press Difference Alert Level
- ▶ Flow Difference Alert Level
- ▶ Block System Menu
- ▶ Block Manual Mode
- ▶ Block Boost Function
- ▶ Automatic Shutdown Time

CHAPTER 4 – APPLICATION SETUP MODE

The Application Setup Mode is used to set up application specific parameters.

APPLICATION SETUP OVERVIEW

The following options are available in Application Setup Mode. After the final setup option is complete, the console will return to the initial setup option.

- ▶ Target Application Rate
- ▶ Pressure Value
- ▶ Speed
- ▶ Reference Flow
- ▶ Tip/Nozzle Capacity

PROGRAM MENU GUIDELINES

Enter the Application Setup Mode

The Master Switch must be off.





Press and release the PROGRAM  button once so the Program User Menu screen appears. Press and release the PROGRAM  button again within 3 seconds to enter the setting options.


Figure 4-1: User Program Menu






Advance to the Next Option



Press the PROGRAM  button to advance the system to the next Program step. After the final setup option is complete, the console return to the initial setup option.

Edit a Setup Option

Press the PLUS  button to increase the value or go to the next option on the list.

Press the MINUS  button to decrease the value or go to the previous option on the list.

Press and hold the PLUS  button or MINUS  button to quickly change the values.

Press and hold the PLUS  button and MINUS  button simultaneously to reset the value to "0".

Exit the System Setup Mode

Press and hold the PROGRAM  button for 3 seconds.

The inputs are stored, and the console will exit the setup mode.

Activate Density Factor



At any time in Application Setup Mode, pressing the AUTO/MAN  button will toggle the density symbol ('D') on or off. When the density symbol is on, the density value (set in System Setup mode) will be used in the regulation algorithms. If the density symbol is off, the density factor will not be used.

Figure 4-2: Density Active



845 Sprayer Control System

INTRODUCTION

INSTALLATION

SYSTEM SETUP

APPLICATION SETUP

OPERATION


APPENDIX

APPLICATION SETUP DETAILS

Target Application Rate

Set target application rate.

Figure 4-3: Target Application Rate




Known Pressure Value

This setting is not available if units are set to “NH3” or lane spraying (GLM or LKM). The pressure field will show “NH3”, “GLM”, or “LKM” when set to these units.

The console will calculate the speed for the selected pressure, Tip/Nozzle type and target rate.

- ▶ If the indicated speed is too high, a set of smaller Tips/Nozzles is required.
- ▶ If the indicated speed is too low, a set of larger Tips/Nozzles is required.

Figure 4-4: Known Pressure Value



Known Speed Calculation

This setting is not available if units are set to “NH3” or lane spraying (GLM or LKM). The speed field will be blank.


The console will calculate what the pressure must be to maintain the target application rate at the entered speed.

- ▶ If the pressure is too high, a set of larger Tips/Nozzles or a slower speed is necessary.
- ▶ If the pressure is too low, a set of smaller Tips/Nozzles or a faster speed is necessary.

Continue trying different speed, pressure, and Tip/Nozzle combinations until the desired combination is found.

NOTE: Known Pressure and Known Speed values are calculators and aids only for customers that have no software connection to the application.

Figure 4-5: Known Speed Calculation




Programmable Tip/Nozzle Reference Flow

This setting is not available if units are set to “NH3” or lane spraying (GLM or LKM). The reference flow field will be blank.

This step is only available if programmable Tip/Nozzle (‘P’) has been selected.

Adjust reference flow for programmable Tip/Nozzle.

Figure 4-6: Reference Flow



Predefined Tip/Nozzle Selection

This setting is not available if units are set to “NH3” or lane spraying (GLM or LKM). The Tip/Nozzle indicator will not be available.

The console will show the reference flow for the selected Tip/Nozzle.

Figure 4-7: Known Tip/Nozzle Capacity




Table 4-1: Tip/Nozzle Sizes and Associated Colors

Established Tip/Nozzle Capacities and Colors	
Size	Color
01	Pure Orange
015	Traffic Green
02	Zinc Yellow
025	Signal Violet
03	Gentian Blue
04	Flame Red
05	Nut Brown
06	Signal Gray
08	Traffic White
10	Light Blue
15	Yellow Green

CHAPTER 5 – OPERATING INSTRUCTIONS

WORK SCREEN

The work screen is comprised of 6 information areas including:



- A. Information Bar - Displays icons to show current modes
 - B. Program Mode
 - C. Density Factor active
 - D. Simulated Speed active
 - E. Flow Meter
 - F. Tip/Nozzle Spacing (Setup mode)
 - G. Section Number (Setup mode)
 - H. Target Application Rate active
 - I. Valve (Setup mode)
 - J. Pressure - Displays current pressure
 - K. Application Rate
 - L. Speed - displays the current speed, when GNSS speed is available, "GPS" will be displayed
 - M. Applied Area / Total Volume Applied - display switches between total applied area and total applied volume
- NOTE: Holding the PROGRAM  button while the Master Switch is on will change the area, marked M, to flow per minute.*
- N. Tip/Nozzle Selection - displays a black arrow over the current Tip/Nozzle capacity Menu Screen

Figure 5-1: Work Screen



BEFORE YOU GET STARTED






Sprayer Check

Before spraying, check all connections related to the Sprayer Control assembly.

WARNING: *Whenever working around a sprayer or farm chemicals, be sure to wear protective clothing and eye wear.*

Partially fill the sprayer tank with water to flush the system and to make a visual check of the spray Tips/Nozzles to be sure all Tips/Nozzles are delivering a good spray pattern.

Follow these steps, in sequence, being sure the Master Switch is in its "OFF" position:

1. Be sure the tank shut-off valve is open.
2. Start the engine, engage pump, and set the RPM to that which will be used when spraying.
3. Switch the console on by pressing the PROGRAM  button on the display panel.
4. Ensure that the spray Tips/Nozzles being used match those selected on the display.
5. Turn "ON" the toggle switches for each of the spray booms on the sprayer.
6. Press the AUTO/MANUAL  button so that the red LED light indicates "MAN" mode.
7. Now, toggle the Master Switch to "ON."
8. Adjust the pressure with the PLUS  button and/or MINUS  button.
9. While spraying, adjust the pressure with the button to the system's minimum point.
10. Now press the PLUS  button for three (3) seconds. This will move the regulating valve to its middle position.
11. Manually adjust the system pressure using a throttle valve in the supply line or a manual shutoff valve on a bypass line. Adjust the system pressure so that it is close to what the operating pressure will be for the application.
12. This ensures a maximum range of automatic adjustment while spraying in AUTO mode. At this point, the sprayer will be activated and spray Tip/Nozzle performance can be visually checked. The pressure adjust buttons can be used to raise or lower the spraying pressure. To stop spraying, toggle the Master Switch to "OFF".

The previous steps provide a quick way to check out the sprayer and consoleized control system.

NOTE: *It is recommended to calibrate the sprayer to prepare the unit for operation, and to diagnose spray Tip/Nozzle wear. Worn Tips/Nozzles can contribute to costly chemical waste, and inaccurate spraying regardless of the use of a sprayer control. Calibration is important and necessary to obtain the benefits associated with a consoleized sprayer control.*

845 Sprayer Control System

INTRODUCTION

INSTALLATION



SYSTEM SETUP

APPLICATION SETUP

OPERATION

APPENDIX

THE SPRAYING OPERATION

1. Switch the console on by pressing the PROGRAM  button on the display panel.
2. Toggle the boom switches to their "ON" position, for each of the booms on your sprayer.
 - Take note of the "numbered" booms on each side of the sprayer, so that the appropriate boom can be toggled "OFF" as necessary.
3. The AUTO/MANUAL  button should be switched to "AUTO."
 - In the AUTO mode, when the Master Switch is "OFF", the target application rate as well as the target symbol will be displayed in the console display. When the Master Switch is "ON", the actual rate will be displayed and the target symbol will no longer appear.

Upon entering the field at the point where spraying will begin, turn the Master Switch to "ON" position. This will activate the spraying operation. Maintain the usual vehicle speed for spraying. Moderate changes in vehicle speed will not affect the application rate, because such changes are compensated by automatic pressure increases or decreases. If for any reason there is a need to stop, turn the Master Switch to "OFF."

Alarm warnings can occur momentarily while the pressure regulating valve is searching for a new setting after the closing of a boom section or other change in normal operation. However, if the alarm stays on for a longer time, the valve may have reached its limit and the system will be unable to regulate flow beyond the limit.

BOOM SECTIONS & SWITCHES

The console operates with, nine (9), seven (7), five (5) or (3) three section switches (depending on console model) and one (1) Master switch. Each section switch is associated with the same number of sections on the boom.

► Switches – control individual boom sections

◀ On – Flip the switch up

◀ Off – Flip the switch down

► Master switch – opens/closes the main product valves and enables/disables power to individual boom section on/off switches

Figure 5-2: Master Switch, 5 Section Switches






OPERATION FEATURES

Tank Level

The tank level menu is used to show and/or set the actual content level in the tank. This level will decrease by the amount being sprayed. If the minimum tank level has been set to a value greater than zero and the actual level becomes less than the minimum level, a tank alarm will be triggered. Setting minimum tank level to zero will disable tank alarm function.

View Tank Level

The current tank level will be displayed.

1. Start from the work screen with the Master Switch "OFF".
2. Press and release the PLUS  button and MINUS  button simultaneously.
3. Press the PROGRAM  button to exit to normal work screen.

Adjust Tank Level

Maximum Tank Size is set in System Setup menu, see Chapter 3 for information.

NOTE: Tank level cannot be set higher than the maximum level.






1. Start from the work screen with the Master Switch "OFF".
2. Use the PLUS  and MINUS  buttons.
Or Press the MAN/AUTO  button to reset tank level to maximum.
3. Press the PROGRAM  button to confirm the selection and exit to normal work screen.




Figure 5-3: Tank Level



Clear Counters


The Clear counters menu is used to reset the total area, total volume and total distance counters to zero.

To clear the counters:

1. Start from the work screen with the Master Switch "OFF".
2. Press and hold the MAN/AUTO  button for 3 seconds.
3. Use the PLUS  or MINUS  buttons to select "YES".

4. Press the PROGRAM  button to confirm the selection and exit to normal work screen.

Figure 5-4: Clear Counters



Simulated Speed

Simulated ground speed allows the verification of console functions and the sprayer without actually moving the sprayer.

The console has a low and high simulated ground speed that allows for switching between the two to simulate a speed change. This will ensure that the console is regulating properly during sprayer checkout.

Activate the Simulated Speed

While on the work screen without the machine in motion and the Master Switch in the "On" position:






- ▶ Activate Low Simulated Speed – While pressing and holding the PROGRAM  button, press and release the MINUS  button. The controller will start regulation using this speed.
- ▶ Activate High Simulated Speed – While pressing and holding the PROGRAM  button, press and release the PLUS  button. The controller will start regulation using this speed.

Figure 5-5: Simulated Speed



845 Sprayer Control System

INTRODUCTION

INSTALLATION

SYSTEM SETUP

APPLICATION SETUP

OPERATION

APPENDIX

Deactivate Simulated Speed

Once the sprayer begins moving and the console receives actual speed pulses, simulated ground speed is deactivated. If a Radar/GNSS Speed Sensor is being used, disconnect the Radar/GNSS from the main console. Due to the sensitivity of this speed sensor, any movement can disable simulated speed.

Simulated speed will also be deactivated if the console is powered off.

Manual/Automatic Regulation Mode

In manual mode, automatic rate regulation is stopped completely. Pressing the PLUS \oplus button simply moves the regulating valve to increase the flow (or increase the PWM duty cycle) as long as the button is pressed. Pressing the MINUS \ominus button gives the opposite action. The valve (or the PWM duty cycle) stays in the position it had, when the PLUS \oplus or MINUS \ominus button was released. The application rate value shown on the screen is the actual rate for the given speed. Since automatic regulation is stopped, it will appear that the rate value changes when the speed is changed.

NOTE: Access to manual mode may be blocked completely in OEM menu.

1. Use the AUTO/MAN \leftrightarrow button to switch between manual and automatic regulation modes.

Figure 5-6: Manual Regulation Mode




Figure 5-7: Automatic Regulation Mode



Boost Function

The boost function is used to increase or decrease the application rate by increments of 10%. When the rate has been changed via the boost function, regulation is still fully functional. The rate is still regulated but target rate is simply increased or decreased by the percentage selected.

NOTE: Access to boost function may be blocked completely in OEM menu!


Boost function can be activated at any time from normal work screen with the Master Switch "ON".

Increase/Decrease Target Application Rate

1. Press the PLUS \oplus button or MINUS \ominus button.
2. Within 3 seconds (while the boost activation period is active), use the PLUS \oplus button or MINUS \ominus button, to increase or decrease the rate in steps of 10%.

After the activation period, the display will revert to normal, but if the rate has been changed, the target symbol will stay visible and flashing.

Figure 5-8: Boost Activation Period Active



Reset Target Application Rate

Reset the target value to the set rate. See Target Application Rate in Chapter 4 for details on the set rate.

1. Press the PLUS  and MINUS  buttons simultaneously.


Regulation Indicator

The LED indicator shows when the console is regulating upwards or downwards (i.e. moving the regulating valve or changing the PWM). The intensity of the LED light is proportional to the speed of change.

Examples: In bypass mode, the LED will be green when regulating upwards or orange when regulating downwards.

In throttle mode, the LED will be orange when regulating upwards or green when regulating downwards.

Figure 5-9: Regulator Indicator



Automatic Power Down

The console is designed to power itself off after 10 minutes of inactivity (or at the time specified in the Automatic Power Down setting in the OEM Setup Mode). This feature keeps the console from draining the battery on the sprayer, if the operator inadvertently leaves the console powered on for an extended period.

Automatic Power Down only occurs when the Master Switch is in the "Off" position.

To manually power down the console, refer to "Power" in Chapter 1.

NOTE: The Automatic Power Down feature is not available when the console is in any program mode.







Smart Sensing




With both a pressure and flow sensor installed, the console determines when the flow rate has dropped below the capacity of the flow meter being used and will automatically switch to pressure-based regulation. When the flow rate reaches an acceptable level for the flow meter to regulate, the console will switch back to flow-based regulation.

845 Sprayer Control System

Audible Alarms

A number of sensor alarms have been included in the 845 software. The alarm system is only active with Master on. All audible alarm signals can be cancelled by pressing any button. All alarms are reset when Master is switched off.

Alarm Name	Examples	Description	Audible Alarm Type
Rate Alarm		Too high difference between target and actual rate.	High Priority (3 short beeps, repeated every second)
No Speed Alarm		If speed is zero with master on, then no speed alarm is triggered and spraying is stopped.	Medium Priority (2 short beeps, repeated every second)
No Flow Alarm		If no flow Pulses are received with master on and flow meter installed, a no flow alarm is triggered.	Medium Priority (2 short beeps, repeated every second).
No Pressure Alarm		If no pressure is measured with master on and pressure sensor installed, a no pressure alarm is triggered.	Medium Priority (2 short beeps, repeated every second).
Low Pressure Alarm		If pressure drops below minimum value with master on, a low-pressure alarm is triggered.	Medium Priority (2 short beeps, repeated every second).
Low Speed Alarm		If speed drops below minimum value with master on, a low-speed alarm is triggered and spraying is stopped.	Medium Priority (2 short beeps, repeated every second).

Alarm Name	Examples	Description	Audible Alarm Type
Pressure Difference Warning		With flow based regulation, the controller (if pressure sensor installed) will compare the actual measured pressure with the calculated pressure (based on flow and Tip/Nozzle type).	No audible alarm.
Flow Difference Warning		With pressure based regulation, the controller (if flow meter installed) will compare the actual measured flow with the calculated flow (based on pressure and Tip/Nozzle type).	No audible alarm.
Tank Level Alarm		Current tank level drops below tank minimum.	Low Priority (1 short beep, repeat every second).

CONFIGURATIONS

System Setup

Description	User Setting
Units	
Restore Defaults	
Speed Sensor Calibration	
Distance Counter	
Pressure Sensor Installed	
Pressure Sensor, Low Pressure Calibration	
Pressure Sensor, Maximum Rating	
Minimum Pressure	
Flow Meter Installed	
Flow Meter Calibration	
Flow Sensor Minimum Flow Capacity	
Regulation Mode	
Tip/Nozzle Spacing	
Number Of Sections	
Tips/Nozzles Per Section	No. 1
	No. 2
	No. 3
	No. 4
	No. 5
	No. 6
	No. 7
	No. 8
	No. 9
Density	
Regulation Valve Type	
Regulation Speed Factor	
Section Valve Type	
Tank Size	
Minimum Tank Level	
Communication Mode	
GNSS Speed	
Variable Rate	
Simulated Ground Speed — Low Speed	
Simulated Ground Speed — High Speed	
Minimum Speed	

OEM Menu

Description	User Setting
Minimum Regulation Valve Voltage	
Regulation Dead Band	
Regulation Time From Minimum to Maximum	
PWM Minimum	
PWM Maximum	
PWM Frequency	
Display Stabilization Percentage	
Master Relay Installed	
Press Difference Alert Level	
Flow Difference Alert Level	
Block System Menu	
Block Manual Mode	
Block Boost Function	
Automatic Shutdown Time	


Application Setup

Description	User Setting
Target Application Rate	
Pressure Valve	
Speed	
Reference Flow	
Tip/Nozzle Capacity	

845 SPRAYER

U S E R M A N U A L



A Subsidiary of  *Spraying Systems Co.*

www.teejet.com