

OPERATOR'S MANUAL



Figure 52

System Wiring Diagram, Truck Harness and Sensors (P/N 46649-0485 and 46649-0486)

Note: Alpha characters in front of pin numbers indicate pin numbers of console connector.

